



## ▼ Turn on/off

If the light is turned off, first switch it on at the wall and then press 'Speed/⚙️🔌' to turn it on. To turn the light off, press and hold the 'Speed/⚙️🔌' button for two seconds.

## ▼ Stationary Colour

Press 'Color' to change the Sydney Opera House lamp to a stationary light colour. Pressing 'Color' again cycles through a range of 20 colour options:



## ▼ Animated Light

Press 'Mode/Demo' to change the Sydney Opera House lamp to an animated light setting. Pressing 'Mode/Demo' again cycles through a range of different settings in the order below.

|  |              |              |          |                 |             |              |                  |           |                 |
|--|--------------|--------------|----------|-----------------|-------------|--------------|------------------|-----------|-----------------|
| <b>CYCLE</b><br>Instantly switches between colours                     | 1.  RGB      | 2.  RAINBOW  |          |                 |             |              |                  |           |                 |
| <b>FLASH</b><br>Flashes a single colour on and off                     | 3.  RED      | 4.  GREEN    | 5.  BLUE | 6.  LIGHT GREEN | 7.  MAGENTA | 8.  CYAN     | 9.  COOL WHITE   |           |                 |
| <b>GRADIENT</b><br>Smoothly transitions between multiple colours       | 10.  RGB     | 11.  RAINBOW |          |                 |             |              |                  |           |                 |
| <b>PULSE</b><br>Smoothly fades a colour on and off.                    | 12.  RGB     | 13.  RAINBOW | 14.  RED | 15.  GREEN      | 16.  BLUE   | 17.  MAGENTA | 18.  LIGHT GREEN | 19.  CYAN | 20.  COOL WHITE |
| <b>FLASH MULTICOLOR</b><br>Flashes between multiple colours            | 21.  RAINBOW | 22.  RGB     |          |                 |             |              |                  |           |                 |
| <b>DEMO</b><br>Plays all of the different animation modes back to back | 23.  ALL     |              |          |                 |             |              |                  |           |                 |

## ▼ Adjust Speed

Press 'Speed/⚙️🔌' to change the speed of the animated light modes. Please note: The speed can only be adjusted while in the animated light modes.

## ▼ Adjust Brightness

Press 'Speed/⚙️🔌' to increase the brightness of the light. Please note: The brightness can only be adjusted while in the stationary colour mode. For the animated light settings, first press 'Color', adjust to desired brightness, then swap back.